

citri★star

The Citrus Pro



OPERATION MANUAL

**SAVE THIS MANUAL- KEEP IT HANDY FOR QUICK REFERENCE
READ INSTRUCTIONS BEFORE USING**

Table of Contents

• Important Safety Instructions	3
• Warranty	4
• Warranty Registration Card	Insert
• Parts List and Assembly	6
• Preparing the CitriStar for Use	6
• CitriStar Assembly and Operation	7
• Cleaning the CitriStar	8
• When You Need Service	9

Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed, including the following:

1. Read all instructions before use.
2. To protect against risk of electrical shock, do not immerse the electric cord, plug, or motor base in water or other liquid.
3. Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning. Remove the plug by gripping the plug body and pulling out of the outlet. Never yank or twist cord to unplug the unit.
4. Close supervision is necessary when any appliance is used by or near children.
5. Avoid contact with moving parts.
6. Do not operate any appliance with a damaged cord/plug or after the appliance malfunctions, or is dropped or damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, electrical, or mechanical adjustment.
7. The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.
8. Do not use outdoors.
9. Do not let cord hang over the edge of table or counter, or touch hot surfaces.
10. To disconnect juicer, wait until motor stops before removing plug from the electrical outlet.
11. Do not operate unattended. Make sure the motor stops completely before disassembling. Unplug after each use.

SAVE THESE INSTRUCTIONS

©2004 Tribest Corp.

No copies, transmission, or translation into other languages of this manual by any means without written permission of Tribest Corp. is allowed. All rights are reserved.

Warranty

We warrant to you, the end-user customer who has properly registered after purchasing the CitriStar Citrus Juicer for a valuable consideration, that the plastic parts and motor will be free from defects in materials and workmanship for a period of 1 year from the date of purchase. Warranty does not cover normal wear and tear.

In order for you to receive the benefits of this warranty, you are required to complete and mail the warranty registration card, containing all the requested information, to us within ten (10) days following the purchase of your CitriStar.

1. No warranty will be provided until after we have actually received the enclosed warranty registration card, containing all the requested information, within ten (10) days of the date of original purchase. The warranty is only good for the original purchaser for value. This warranty is non-transferable.
2. If the CitriStar exhibits defects while in normal household use, we, upon our actual receipt of a written notice of such defects from you during the warranty period, we will, at our option, either repair or replace the CitriStar which prove to be defective. However, we have no such obligation to repair or replace until after you have, by insured mail and in protective packaging*, delivered the CitriStar to the location of your service center as set forth. Replacement CitriStar may be either new or like new. CitriStar may contain re-manufactured or reconditioned parts, which are equivalent to new in performance or may have been subject to incidental use.
3. We do not warrant that the operation of the CitriStar will be uninterrupted or error free. In no event shall our liability exceed the retail value of the CitriStar.
4. All warranty and repair services must be performed at a warranty service center, which is located within the country where the machines was originally purchased. However, in the event that: [i] the machine must be serviced at a service center, which is not located within the country where the machine was purchased; or [ii] there is no service center within the country where the machine is located and must be shipped to a service center in another country, then those service centers are responsible for the parts and service only, and any and all costs relating to the shipping, delivery and handling of the machine to and from those service center shall be the sole responsibility of the owner.

This warranty does not cover defects resulting from: [a] failure to operate the CitriStar in accordance with the instructions; [b] use of parts or supplies not provided or authorized by us; [c] negligent, improper or inadequate maintenance; [d] service performed or attempted by unauthorized service person; [e] damages, accidental or otherwise, to the CitriStar, which are not directly caused by us or the manufacturer; or [f] damages resulting from abuse, tampering, misuse, commercial use, or unauthorized modification of the CitriStar.

WE MAKE NO OTHER EXPRESS OR IMPLIED WARRANTY OR CONDITION WHETHER WRITTEN OR ORAL TO THE EXTENT ALLOWED BY LOCAL LAW, ANY IMPLIED WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE OR IMPLIED WARRANTY OR CONDITION OF MERCHANTABILITY IS LIMITED TO ONE (1) YEAR. In the event that such limitation or exclusion on the duration of an implied warranty is not allowed in the state or country wherein you reside, the above limitation or exclusion will not apply. This warranty gives you specific legal rights and protection, and you might also have other rights that vary from state to state, or country to country.


TO THE EXTENT ALLOWED BY LOCAL LAW, THE REMEDIES IN THIS WARRANTY STATEMENT ARE YOUR SOLE AND EXCLUSIVE REMEDIES. EXCEPT AS INDICATED ABOVE, IN NO EVENT WILL WE BE LIABLE FOR DIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL (INCLUDING LOST PROFIT, OR OTHER DAMAGE, WHETHER BASED IN CONTRACT, TORT, OR OTHERWISE). Some states or counties may not allow the exclusion or limitation of incidental or consequential damages. If you reside in such a state or county, the above limitation or exclusion may not be applicable.

Do not send your CitriStar back to the service center without a return authorization.

***Save Original Shipping Box**

Juicer Part Description

Parts are listed according to this photo from the top down.



Preparing the CitriStar for Use

Always clean the Ream, Screen, Juice Collector, and Spout before using the appliance for the first time.

CitriStar Assembly and Operation



1. Place the appliance on a firm and level surface out of reach of children.
2. Put the Juice Collector in place correctly. (fig. 1)
3. Put on the Screen. (fig. 2)
4. Insert the Ream. (fig. 3) Plug in.
5. Switch the appliance on by pressing the halved fruit firmly onto the ream. The juice will be extracted quietly and quickly. (fig. 4) **CAUTION:** Recommend 15 seconds of operation followed by 15 seconds rest. Do not operate more than 5 minutes at one time and allow a few minutes rest before next use.
6. Put a container under the spout. Flip the spout down towards the container. The instant flow system guides juice directly into the vessel. (fig. 5) After you have finished, flip the spout up to prevent dripping and spilling of juice. (fig. 6) *Always clean the appliance immediately after each use.*
7. Wrap the cord under the CitriStar base and exit cord through the opening in the back of the appliance. If necessary, wind excess cord around. (fig. 7)

Cleaning the CitriStar

1. Unplug the cord from the electrical outlet. Remove the ream, screen, and juice collector from the appliance.
2. Flip the spout down fully in order to clean it properly. The spout cannot be detached from the appliance.
3. Clean the ream, screen, and juice collector by using warm soapy water. Dry all parts. Do not clean parts in a dishwasher.
4. Clean the motor base by using a moist cloth. Never immerse the motor base in water or rinse it under running water.

When You Need Service

In the unlikely event that you do need service on your CitriStar, or if it fails to function properly while within the warranty period (normal household operation only) - contact the nearest authorized CitriStar Service Center. PLEASE FOLLOW THE INSTRUCTIONS BELOW:

SERVICE CENTER

USA: Tribest Corp. 14109 Pontlavoy Ave., Santa Fe Springs, CA 90670, USA
TEL: 562-623-7150; 888-254-7336. FAX: 562-623-7160
EMAIL: service@tribest.com WEBSITE: www.tribestlife.com

- Call to obtain a return authorization number to send your unit or part back to the service center. Explain the problem you are experiencing.
- Pack your CitriStar or part securely in the original shipping box. Make sure all necessary parts are enclosed. Fill out the Service Request Form below, detach it and enclose it in the shipping box.
- Securely seal the shipping box with strapping tape.
- Address the box to the service center. Be sure to put your return address and the Return Authorization Number on the outside of the package.
- It is always wise to insure the package against possible damages or loss in transit. Ship prepaid.

-----Detach Form on Dotted Line-----

Service Request Form

1. First Name _____ Initial _____
Last Name _____ Apt # _____
Address: Street _____
City _____ State _____ Zip _____
Phone _____
2. Serial # _____ Model# _____
3. Reason for service request _____
4. Date of Purchase _____ 5. Place of Purchase _____
6. Name of parcel/post carrier (In case of damage during delivery) _____

PRODUCT STANDARD	
ITEM	CITRUS JUICER
MODEL	CS-1000
VOLTAGE	AC 120V/220V
FREQUENCY	60HZ/50HZ
ELECTRIC POWER	50W/85W
SIZE	(220 x 150 x 150) MM (8.7 x 5.9 x 5.9) Inch
WEIGHT	3.5 KG (7.7 Lbs)

TRIBEST

Tribest Corporation

P.O. Box 4089, Cerritos, CA 90703

Toll Free: 888-618-2078

Tel: 562-623-7150

Fax: 562-623-7060