



ATTENTION

If any components of this unit are broken, do not operate properly, or for product returns, please contact Pragotrade LLC at

1-800-814-4895

Outside the U.S. call 440-638-3131.

For the online catalog, log onto www.westonsupply.com.

Exclusively imported by Pragotrade LLC Strongsville, Ohio www.pragotrade.com

ADDITIONAL ACCESSORIES AVAILABLE

Food-Grade Silicone Spray	03-0101-W
Cereal & Multi-Grain Mill	36-3601-W
Non-Stick Single Hamburger Press	07-0301
Traditional Style Pasta Machine	01-0201
Stainless Steel Mandoline Vegetable Slicer	01-0006
Restaurant Quality French Fry Cutter	36-3501-W
Sauce Maker & Food Strainer	07-0801

These products and many more products can be ordered by visiting

www.westonsupply.com or by calling

Pragotrade LLC Toll Free at 1-800-814-4895

Monday thru Friday 8:00am-5:00pm EST.

Outside the U.S. call 440-638-3131

WESTON
HEAVY-DUTY
SLAW BOARD
& CABBAGE SHREDDER
MODEL NO. 70-1401-W




WARNING
SHARP BLADES
 KEEP FINGERS CLEAR
 OF BLADE AREA!
 Protective/cut-resistant
 Kevlar Gloves are
 recommended whenever
 handling the Blades!

GENERAL SAFETY RULES

READ AND FULLY UNDERSTAND ALL INSTRUCTIONS AND WARNINGS PRIOR TO USING THIS UNIT. YOUR SAFETY IS MOST IMPORTANT! FAILURE TO COMPLY WITH PROCEDURES AND SAFE GUARDS MAY RESULT IN SERIOUS INJURY OR PROPERTY DAMAGE. **REMEMBER: YOUR PERSONAL SAFETY IS YOUR RESPONSIBILITY!**

1. Keep fingers clear of the **Blade** at all times. **NEVER** push the product with your hands in line of the **Blade**, **ALWAYS** use the **Sliding Carriage**.
2. **KEEP CHILDREN AWAY. NEVER LEAVE THE SHREDDER UNATTENDED.**
3. The Manufacturer declines any responsibility in the case of improper use of this **Shredder**.
4. **DO NOT** use the **Shredder** while under the influence of drugs or alcohol.

SAVE THESE INSTRUCTIONS

REV091609

If any components of this unit are broken or the unit does not operate properly, call Pragotrade LLC Toll Free at


1-800-814-4895

Monday thru Friday 8:00am-5:00pm EST.

Outside the U.S. call 440-638-3131


WESTON

HEAVY-DUTY SLAW BOARD & CABBAGE SHREDDER



HOW TO USE THE SLAW BOARD & CABBAGE SHREDDER

1. Cut the cabbage or leafy vegetable head into quarters or a size that will fit into the wooden **Sliding Carriage**.
2. Slide the **Sliding Carriage** into the groove on the **Cabbage Shredder Base**. **NEVER** use the **Cabbage Shredder** without the **Sliding Carriage**! **SEVERE INJURY MAY OCCUR!**
3. Place the sectioned cabbage into the **Sliding Carriage**.
4. Hold the **Cabbage Shredder** at a 45° angle over a pan. The sharp **Blade** edges should be facing up.
5. To hold the cabbage in the **Sliding Carriage**, place four fingers on the top of the cabbage and your thumb on the outside of the **Sliding Carriage**. **DO NOT** allow fingers or thumb to come in contact with the **Base** and the **Blades**. **CAUTION! SHARP BLADES!** *Figure 1*
6. With up and down, quick motions, slide the **Sliding Carriage** while applying pressure to the cabbage. The sliced cabbage will fall through the bottom of the **Cabbage Shredder** into the pan.
7. **USE CAUTION!** When the cabbage in the **Sliding Carriage** becomes approximately 2" (5 cm) thick, **STOP SLICING!** Cut the small left-over pieces by hand. **Blades** are very sharp and may lead to serious personal injury if the cabbage gets too small. **CAUTION! SHARP BLADES!**



CLEANING INSTRUCTIONS

To clean the **Slaw Board & Cabbage Shredder**, hand wash with warm, soapy water. Rinse with clean water and dry immediately. **CAUTION! SHARP BLADES!** Avoid any contact with the **Sharp Blades!** This product is NOT dishwasher safe.

NOTE: It is highly suggested to coat the **Blades** with a food-grade silicone spray to prevent corrosion.

WARRANTY INFORMATION

SAVE THIS WARRANTY INFORMATION FOR YOUR RECORDS!

Pragotrade LLC warrants to the ORIGINAL RETAIL PURCHASER of this product that if operated in accordance with the printed instruction accompanying it, then for a period of 1 year from the date of purchase, the product shall be free from defects in material and workmanship.

The Warranty Card, along with a copy of the original receipt, must be received by Pragotrade LLC within 30 days from purchase date for the warranty to apply. Failure to send the completely filled out Warranty Card, along with a copy of the original receipt, will void the warranty.

The product must be delivered to or shipped freight prepaid to Pragotrade LLC for warranty services, in either its original packaging or similar packaging affording an equal degree of protection. Damage due to shipping is not the responsibility of the company. Pragotrade LLC charges a \$35.00 per hour bench charge. **NOTE:** No repairs will be started without the authorization of the customer. The return shipping cost to the customer will be added to the repair invoice.

Pragotrade LLC will repair (or at its discretion, replace) the product free of charge, if in the judgment of the company, it has been proven to be defective as to seller's labor and material, within the warranty period.

New or rebuilt replacements for factory defective parts will be supplied for one (1) year from the date of purchase. Replacement parts are warranted for the remainder of the original warranty period.

For non-warranty repairs, contact Pragotrade's Customer Service at 1-800-814-4895 M-F 8am-5pm EST (outside of the United States 440-638-3131) to obtain a Return Authorization Number (RMA Number). Pragotrade will refuse all returns that do not contain this number. **DO NOT RETURN THE UNIT WITHOUT PROPER AUTHORIZATION FROM PRAGOTRADE LLC.**

LIMITATIONS: The warranty is void if the product is used for any purpose other than that for which it is designed. The product must not have been previously altered, repaired, or serviced by anyone else other than Pragotrade LLC. If applicable, the serial number must not have been altered or removed. The product must not have been subjected to accident in transit or while in the customer's possession, misused, abused, or operated contrary to the instructions contained in the instruction manual. This includes failure caused by neglect of reasonable and necessary maintenance, improper line voltage and acts of nature. This warranty is not transferable and applies only to U.S. and Canadian sales.

Except to the extent prohibited by applicable law, no other warranties whether expressed or implied, including warranty merchantability and fitness for a particular purpose, shall apply to this product. Under no circumstances shall Pragotrade LLC be liable for consequential damages sustained in connection with said product and Pragotrade LLC neither assumes nor authorizes any representative or other person to assume for it any obligation or liability other than such as is expressly set forth herein. Any applicable implied warranties are also limited to the one (1) year period of the limited warranty.

This warranty covers only the product and its specific parts, not the food or other products processed in it. **CUT ALONG THE DOTTED LINE AND SEND THE WARRANTY CARD ALONG WITH A COPY OF YOUR ORIGINAL PURCHASE RECEIPT TO:**

Pragotrade LLC
20365 Progress Drive, Strongsville, OH 44149

WARRANTY CARD

SEND THIS CARD ALONG WITH A COPY OF YOUR ORIGINAL PURCHASE RECEIPT

Customer Name: _____

Address: _____

City/State/Zip: _____

Telephone Number: (____) _____

E-Mail Address: _____

Original Date of Purchase: ____/____/____

Product Model #: _____

Serial # (if applicable): _____